

KD - TRICK BINDING MOUNTING AND PLACEMENT

RECOMMENDED FRONT BINDING PLACEMENT

MEASURE FROM REAR OF SKI TO REAR OF HEEL ON FRONT BINDING

41"	17 1/2"
42"	18"
43"	18 1/2"

ALWAYS CHECK SCREW LENGTHS AND THREAD TYPE

Only use hand screw driver to start and tighten screws to avoid cross threading of screws and inserts

